

Brake Cleaner

Brake Cleaner is a highly concentrated cleaner with acetone suited for all maintenance and assembly work. Cleans heavily soiled substrates. Degreases and removes resins. Produces bright clean surfaces.

Brake Cleaner is used to

- remove oil, grease, resin, adhesive and clutch/brake debris
- clean engine parts, springs, electric installations, starters, roller bearings and guides
- remove stubborn stains from upholstery and textiles
- works without leaving any residues

Use:

Spray dirty parts thoroughly and let the fluid run off. Repeat the treatment if necessary. Test plastics, rubber, coloured substrates and textiles in an inconspicuous area for compatibility before use.

Content of aerosol can:

500 ml

Suggestions, processing and use of our products correspond to the best knowledge at printing of this leaflet and are always given without obligation. You only can serve as a clue in consideration of the changing conditions; from this no liabilities, liability and guarantee claims can be derived. Own tests must be carried out before application. Every manufacturer of our products is liable for the retention everything legal to regulations.